

Your Prep/Master® is built to go over 200,000 SF/20,000 M² before it needs any of these parts.

In the real world, though, we know accidents happen and freight bills for overnight delivery are expensive. This kit is your perfect preparation for the unexpected!



It's a System











Not a Machine



THE COMPLETE System... **P/M REPAIR KIT**

Item# 429014602

P/M Repair Kit Contents

	Part Number	Description	Qty.
	880000602	Morflex Coupler 602	2
	570000014	EG Female Adapter Quick Change for P/M	3
	881102012	Woodruff Key	2
	18918	Coupler 502 & 602-Bolt (1/2-20 x 3")	8
	33895	Coupler 502 & 602-Split Lock Washer (1/2")	8
	38617	570000014 Bolt (M8x30)	6
	40383	570000014 Lock Washer (M8)	6
	40357	570000014 Flat Washer (M8)	6

Substrate Technology, Inc.
1384 Bungalow Rd., Morris, IL 60450

+1.815.941.4800
www.SubstrateTechnology.com