



## Assembly Manual BDC-66 Longopac





### Hardware list:

- 10 x BE0010\_M10x40 hexagon head screw DIN933
- 14 x BE0006\_M10 spring lock washer DIN127B
- 14 x BE0004\_M10 plain washer DIN125A
- 2 x BE0021\_M8x16 hex. socket head cap s. DIN912
- 2 x BE0003\_M8 plain washer DIN125A
- 2 x BE0048\_M8 hexagon locking nut DIN-985
- 4 x BE0273\_M6 hexagon locking nut DIN-985
- 6 x BE0016\_M6 plain washer DIN125A
- 4 x BE0038\_M10x20 hexagon head screw DIN933
- 2 x BE0188\_M6x25 hex. socket head cap s. DIN912