

P-3200 Inverter Programming  
Set Menu

Units

ACC	3	s
dEC	3	s
LSP	0	Hz
HSP	60	Hz
ItH	27.7	A
UFr	70	%
tdC1	0.5	s
SdC1	19.3	A
tdC2	0	s
SdC2	13.8	A
JPF	0	Hz
JF2	0	Hz
SP2	10	Hz
SP3	15	Hz
SP4	20	Hz
CL1	41.5	A
tLS	0	s
Ftd	60	Hz
ttd	100	%
Ctd	27.7	A
SdS	30	
SFr	4	kHz

drC Menu

bFr	60	Hz
UnS	460	V
FrS	60	Hz
nCr	17.9	A
nSp	1760	RPM
COS	0.85	
rSC	n0	
tUs	tAb	
Uft	L	
nrd	YES	
SFr	4	kHz
tFr	72	Hz
SrF	n0	

I/O Menu

tCC	2C	
tCt	trn	
rrS	L12	
Cr13	4	mA
CrH3	20	mA
AOIt	0A	
d0	n0	
r1	rUn	
r2	rUn	

CtL Menu

LAC	L1	
Fr1	A11	
Fr2	n0	
rFC	Fr1	
COP	n0	
LCC	n0	
PSt	YES	

FUn Menu

rPC-	rPt	L1n	
	lnr	0.1	
	ACC		s
	dEC	3	s
	rPS	n0	
	FrT	0	
	brA	Yes	
StC-	Stt	nSt	
	FSt	n0	
	dC1	n0	
	nSt	n0	
AdC-	AdC	Yes	
SA1	SA2	AI2	
	SA3	n0	
PSS-	PS2	LI3	
	PS4	LI4	
	PS8	n0	
	PS16	n0	
JOG-	JOG	n0	
PI-	PIF	n0	

FLt Menu

Atr	n0	
rSF	n0	
FLr	n0	
EtF	n0	
EPL	YES	
OPL	YES	
IPL	YES	
OHL	YES	
OLL	YES	
SLL	YES	
COL	YES	
tnL	YES	
LFL	n0	
LFF	10	Hz
drn	n0	
StP	n0	
LnH	n0	
rPr	n0	

CON Menu

Add	1
tbr	19.2
tFO	8E1
ttO	10 s
AdCO	0
bdCO	125
FLO	nO