


Each swivel has two sets of seals. One set of seals (Ceramic Seat, Cupped Washer & O-Ring) are installed in the Cap Assembly & one set of seals are installed in the Shaft assembly



Cap Assembly

Body & Shaft Assembly



Shaft

Medium O-ring

Sealed Bearing

Thin Spacer


Open Bearing

Bearing Washer

Brass Spacer

Sealed Bearing

Large O-ring



Ceramic seat

Cupped Washer

Small O-ring

Shaft