



AC39 WATER SOFTENER
MANUAL RECHARGE

PALA11
Head Manual Recharge Softener




Softener Tank Shell

Riser Pipe w/ Bottom Basket




Resin Beads – 1 cubic ft



PALA11
Head Manual Recharge Softener



PALA10
Plug Head Manual Recharge
Softener



BR078
NIPPLE 3/4" HEX



BR319
ADAPTER 3/4" MPT X 3/4" MGH



BR326
CONNECTOR 3/4" FPT X 3/4" FGH